

Assembly Guide For Albany Wall Sheds And Clutterbox

RECOMMENDED TOOLS: HAMMER, CROSS HEAD SCREWDRIVER (BATTERY OPERATED IF AVAILABLE), STANLEY KNIFE, SAW, STEPLADDERS TO FELT ROOF.

**ESTIMATED ASSEMBLY TIME: TWO PEOPLE 1 - 2 HOURS.
WE RECOMMEND PILOT DRILLING SCREW HOLES FIRST.**

PARTS LIST	
A: 1 X FLOOR PANEL	F: 1 X ROOF SECTION
B: 1 X BACK PANEL	G: 1 X FELT ROLL
C: 1 X LEFT HAND END	H: 1 X TRIM PACK
D: 1 X RIGHT HAND END	I: 1 X NAIL & SCREW PACK
E: 1 X FRONT PANEL	

1. Lay the floor panel (A) in its desired position (remember to leave enough space around the building for roof overhang and maintenance). It is essential the floor is on a solid level base otherwise the building will not fit together properly and the door may not fit flush. Place the panels around the floor - it will help you understand how they fit together.

2. Position the back panel (B) on the back edge of the floor (the lip on the bottom overhangs the floor). While your assistant holds the back place an end panel (C/D) on the floor to form a corner. Check that the panels are sitting flat on the floor and are butted together, fix together from the inside screwing through the end into the back using two of the screws provided.

3. Select the other end panel (C/D) and place on the floor, screw to the back as before with two screws, again making sure the sections are flat on the floor.

4. Place the front panel (E) in the remaining space and screw the front to the ends from the inside as before.

5. Place the roof section (F) on the building. The shed may need pushing into square at this stage to allow the roof panel to drop into place. Before fixing check that the roof is sitting flat with the sides, if not it is possible the floor is not level and will need packing in one corner.

6. With the roof square check that all the walls are sitting flat on the floor. Screw the panels to the floor using two screws per panel, ensuring that you screw into a floor joist (follow the lines of nails in the floor to locate the joists).

7. Check that the roof overhang is equal to the front and back (or as required) secure the roof by nailing through the roof into the framing on the sides and ends.

8. Felt the roof using the small clout nails provided. Start by carefully undoing the felt (G).

Place the strip on the roof so it overhangs each side, front and back. Secure to the front framing every 100 – 150mm starting from the center. Pull tight to the back and nail flush with the framing every 100 – 150mm as before. Repeat on the sides.

9. Open the trim pack (H) and remove the bargeboards, nail them to the sides of the roof, trim the felt if necessary.

We recommend you treat your building within six months and from then on annually with a recognized brand of spirit based preservative.

Barrettine red cedar can be ordered from you local dealer in 5L cans

These instructions are meant as a guide only we reserve the right to alter design without prior notice.

Thank you for buying an Albany Shed.

www.albanysheds.co.uk

