

Assembly Guide For 1008 Farndon Summerhouse

RECOMMENDED TOOLS: HAMMER, CROSS HEAD SCREWDRIVER (BATTERY OPERATED IF AVAILABLE), STANLEY KNIFE, SAW, STEPLADDERS TO FELT ROOF. 10MM SPANNER OR SOCKET ESTIMATED ASSEMBLY TIME: TWO PEOPLE 2 - 4 HOURS. WE RECOMMEND PILOT DRILLING SCREW HOLES FIRST.

PARTS LIST	
A: 2 X FLOOR PANELS	G: FELT ROLLS (QTY DEPENDS ON SIZE)
B: 1 X FRONT PANEL	H: FASCIA BOARDS (TRIM PACK)
C: 1 X BACK PANEL	I: FILLER STRIPS (TRIM PACK)
D: 1 X LEFT HAND SIDE PANEL	J: CORNER STRIPS (TRIM PACK)
E: RIGHT HAND SIDE PANEL	K: GLASS – 16 DOOR, 18 WINDOW
F: 2 X ROOF SECTIONS	1 X NAIL, SCREW & HANDLE PACK

1. Lay the floor panel (A) in its desired position (remember to leave enough space around the building for roof overhang and maintenance). It is essential the floor is on a solid level base otherwise the building will not fit together properly and the door may not fit flush. Join the floor panels together by nailing into the joining blocks on one piece of floor. Place the panels around the floor - it will help you understand how they fit together.

2. Position the back gable (C) on the back edge of the floor (the lip on the bottom overhangs the floor). While your assistant holds the gable place a side panel (D/E) on the floor to form a corner. Check that the sides are sitting flat on the floor and the panels are butted together, screw them together from the inside using two of the screws provided.

3. Select the other side panel (D/E) and place on the floor, screw to the plain gable as before with two screws, again making sure the sections are flat on the floor.

4. Before fitting the door gable (B) remove the key from the inside of the door. Unlock the door and attach the handles (J), screw the door gable to the sides from the inside as before.

5. Place the roof sections (F) onto the building, one end of the roof is closed in, this end goes to the low side of the building. Screw the roof sections together.

before fixing to the walls open the trim pack and locate the filler strip (I - long strip approx 45mm wide) fix the soffit boards underneath the roof from the outside at the front and back as shown in the diagram by nailing into the joists using 40mm nails.

6. Check that the roof is sitting flat with the ends, if not it is possible the floor is not level and will need packing in one corner. Check that the roof overhang is equal all the way round then secure the roof by screwing from underneath through the front and back into the roof framing, and also by nailing through the roof boards into the ends using 50mm nails.

7. With the roof square check that all the walls are sitting flat on the floor. Screw the panels to the floor using two screws per panel, ensuring that you screw into a floor joist (follow the lines of nails in the floor to locate the joists).

8. Felt the roof using the small clout nails provided. Start by carefully removing the paper from the felt. Roll the felt out on a flat and place the first strip on the roof at the low side so that it overhangs both ends and the rail. Secure with three evenly spaced nails along the upper edge and nail every 100 - 150 mm along the edge into the strip on the roof. Nail the other wide piece of felt so that it overlaps the first piece by 100 - 150 mm. Then place the third strip over the front of the shed and nail flush with the framing every 100 – 150mm from the center, pull tight to the back and nail every 100 – 150mm as before. Fold the ends of the felt and nail into the end of the farming.

9. Remove the barge boards (long strips approx 95mm wide) from the trim pack (H) and nail them to the ends of the roof, the barge board goes at the high side to cover the felt, then trim the felt if necessary.

10. Fix the corner strips (long narrow strips) to each outside corner using three nails per strip

11. Glaze the building from the outside using the beading provided (either in the trim pack or pre fitted in the window). Do not push the beading too tight against the glass or it will crack. You can use panel pins or silicone (not provided) to fix the beading. We advise you wear gloves when handling glass.

We recommend you treat your building annually with a recognized brand of spirit-based preservative – Barrettine Red Cedar can be ordered from your local retailer.

These instructions are meant as a guide only we reserve the right to alter design without prior notice.

Thank you for buying an Albany Product. www.albanysheds.co.uk

