

Assembly guide for Albany Middleton 1008

RECOMMENDED TOOLS: HAMMER, POZIDRIVE SCREWDRIVER (BATTERY OPERATED IS USEFUL), STANLEY KNIFE, SAW, STEPLADDER TO FELT ROOF, PROTECTIVE GLOVES, SPIRIT LEVEL.

ESTIMATED ASSEMBLY TIME: TWO PEOPLE, 3 HOURS.

WE RECOMMEND PILOT DRILLING SCREW HOLES FIRST.

PARTS LIST	
A: 2 x floor section	G: Felt (10m roll)
B: 1 x plain side	H: nail & screw pack
C: 1 x window end	I: 1 x trim pack
D: 1 x window side	J: bench & legs
E: 1 x door end	K: 10 x glass
F: 2 x roof section	

1. Treat the underside of the floor if the building has been supplied untreated. Lay the floor panels (A) in their desired position (remember to leave enough space around the building for roof overhang and maintenance). It is essential the floor is on a solid, level base, otherwise the building will not fit together properly. Fix the two sections together by nailing through the joining blocks (small pieces of timber sticking out of one of the sections) using the 40mm nails. Place the side panels around the floor - it will help you understand how they fit together.

2. Position the plain side (B) on the back edge of the floor (the lip on the bottom overhangs the floor). While your assistant holds this panel, place the window end (C) on the floor to form a corner. Making sure the panels are sitting flat on the floor and are butted together, screw through the window end into the plain side from the inside using two of the screws provided.

3. Select the window side (D) and place it on the floor opposite the plain side. Screw to the window end as before with two screws, again making sure the sections are flat on the floor.

4. Before fitting the door end (E), take the key out and unlock the door. Screw the door end to both sides from the inside as before.

5. Place the roof sections (F) onto the building (the framing sits on panels B and D), one end of the roof is closed in, this end goes to the low side of the building.

Screw the roof sections together. Before fixing to the walls open the trim pack and locate the filler strip (long strip approx 45mm wide). Fix the filler strip underneath the roof from the outside at the front and back by nailing into the joists using small nails.

6. Check that the roof is sitting flat with the ends, if not it is possible the floor is not level and will need packing in one corner. Check that the roof overhang is equal all the way round then secure the roof by screwing from underneath through the front and back into the roof framing, and also by nailing through the roof boards into the ends using small nails.

7. With the roof square check that all the walls are sitting flat on the floor. Screw the panels to the floor using two screws per panel, ensuring that you screw into a floor joist (follow the lines of nails in the floor to locate the joists).

8. Felt the roof using the small clout nails provided. Start by carefully removing the paper from the roll of felt, then roll it out onto a flat, dry surface. Cut it into three equal strips (about 3333mm long). See felt plan overleaf for reference for next part. Place the first strip on the low side of the roof so it overhangs evenly at each end and approximately 50mm over the long side, secure with three evenly spaced nails along the upper edge (you will cover this over later with Strip 2) then fold the 50mm overhang over the side of the roof (creasing it where it bends and keeping it taut) and nail every 100 - 150 mm along the edge of the roof framing, working from the middle outwards. Position Strip 2 on the roof so it is overlapping Strip 1 by 100 - 150mm, hold it in place with three nails at the top, then nail through strips 1 & 2 every 100 - 150mm from the middle outwards. Repeat with Strip 3, creasing the felt where it overhangs the long side and nailing along that side of the roof as well, keeping it taut. Then fold over the loose ends of the felt and nail down in a few places.


9. Open the trim pack and remove the two fascia boards. Nail them to the ends of the roof framing, then trim the felt if necessary using a Stanley Knife.

10. Fix the corner strips (long narrow strips) to each outside corner using three nails per strip (nail at an angle into the framing).

11. Fit the bench by standing the legs in position to get the correct height for the bench, then screw the bench into the upright framing and screw down through the bench into the legs.

12. Glaze the shed by removing the beading pre-fitted to the windows, putting in a pane of glass, then nailing the beading into place using panel pins. Do not push the beading too tight against the glass or it will crack. We advise you wear protective gloves when handling glass.

If your building has been supplied untreated, it requires treating straight away. We recommend you re-treat your building within 6 months and from then on annually. Albany Brown treatment can be ordered from your local retailer in 5 litre tubs. These instructions are meant as a guide only. We reserve the right to alter design without prior notice. Thanks for buying an Albany shed. www.albanysheds.co.uk



Felt plan
1008

Diagram shows 806 model

